






RS-232 Pegel

Baudrate

- 000: 300 8-N-1
- 001: 1200 8-N-1
- 010: 2400 8-N-1
- 011: 4800 8-N-1
- 100: 9600 8-N-1
- 101: 19200 8-N-1
- 110: 38400 8-N-1
- 111: 57600 8-N-1

DE0508

Antennenumschalter

Uwe

Rev 1.01

07.02.2012

Page 1

